

# CASIO®

# SERVICE MANUAL

# & PARTS LIST (without price)

## PX-830BP

OCT. 2009



PX-830BP

**ELECTRONIC KEYBOARD**

**Ver. 4 : Mar. 2010**

**CONTENTS**

**SPECIFICATIONS..... 1**

**BLOCK AND WIRING DIAGRAM ..... 2**

**PCB LAYOUT ..... 3**

**CIRCUIT DESCRIPTION ..... 4**

**PRINTED CIRCUIT BOARDS..... 6**

**DISASSEMBLY ..... 11**

**DIAGNOSTIC PROGRAM ..... 42**

**EXPLODED VIEW..... 49**

**PARTS LIST..... 51**


**SCHEMATIC DIAGRAMS ..... 56**

## SPECIFICATIONS


<b>Keyboard</b>	88-key piano keyboard, with Touch Response
<b>Maximum Polyphony</b>	128 notes
<b>Tones</b>	16 Layer (excluding bass tones) Split (Low-range bass tones only)
<b>Effects</b>	Brilliance (–3 to 0 to 3), Reverb (4 types), Chorus (4 types), DSP, Acoustic Resonance
<b>Metronome</b>	Beats: 0, 2, 3, 4, 5, 6 Tempo Range: 20 to 255
<b>Duet</b>	Adjustable tone range (–1 to 2 octaves)
<b>Music Library</b>	Number of Songs: 60, User Songs: 1 (memory capacity; up to 65 KB)* * Based on 1 KB = 1024 bytes, 1 MB = 1024 <sup>2</sup> bytes Song volume: Adjustable Part On/Off: L, R
<b>Recorder</b>	Functions: Real-time recording, playback Number of Song: 1 Number of Tracks: 2 Capacity: Approximately 5,000 notes total Recorded Data Protection: Built-in flash memory
<b>Pedals</b>	Damper (with half-pedal operation), Soft, Sostenuato
<b>Other Functions</b>	Touch Select: 3 types, Off Transpose: 2 octaves (–12 to 0 to 12) Tuning: A4 = 440.0 Hz ± 99 cents (variable) Temperament Octave shift Operation Lock
<b>MIDI</b>	16-channel multi-timbre receive
<b>SD Memory Card</b>	SD memory card slot Supported SD Memory Cards: Up to 2 GB Functions: SMF playback, file storage, file recall, card format
<b>Inputs/Outputs</b>	PHONES jacks: Stereo standard jacks × 2 Power: 24V DC (Max.) LINE OUT R, L/MONO jacks: Standard jacks × 2 Output impedance: 2.3 KΩ Output voltage: 1.1 V (RMS) MAX  USB port: TYPE B Pedal connector
<b>Speakers</b>	φ 12 cm × 2 (Output 20 W + 20 W)
<b>Power Requirements</b>	AC Adaptor: AD-E24250LW
<b>Power Consumption</b>	24 V --- 60 W
<b>Dimensions</b>	Digital Piano and Stand*: 137.1 (W) × 27.5 (D) × 76.2 (H) cm (54 × 10 <sup>13</sup> / <sub>16</sub> × 30 inch) * Keyboard cover closed.
<b>Weight</b>	Digital Piano and Stand: Approximately 35.2 kg (77.6 lbs)

• Specifications and designs are subject to change without notice.

### BLOCK AND WIRING DIAGRAM



### PCB LAYOUT



PCBs		Components	
Main PCB	M900-MDA1	MPU, Reset IC, SDRAM (256 Mbit), Flash Memory (256 Mbit), FCRAM (32 Mbit), Power Supply Circuit, Key Controller, USB Port	
Sub PCB	M903-PSA1	DC 24 V Terminal, Power Supply Circuit, Filter, Power Amplifier, Headphones Amplifier	
Console PCB	M900-CNA1	Buttons	
Volume PCB	M900-CNA2	Main Volume	
Jack PCBs	M902-HPA1	Phones Jacks	
	M901-JKA1	LINE OUT (R, L/MONO) jacks	
SD Card PCB	M810-SDA1	SD Card Slot	
Power Lamp PCB	M902-HPA2	Power Lamp	
Keyboard PCBs	MACP-KYA1	MACP-KYC1	Keyboard
	MACP-KYA2	MACP-KYC2	
	MACP-KYB1	MACP-KYD1	
	MACP-KYB2		


## CIRCUIT DESCRIPTION

## KEY MATRIX

	KC0	KC1	KC2	KC3	KC4	KC5	KC6	KC7
<b>FI0</b>	A0①	A0#①	B0①	C1①	C1#①	D1①	D1#①	E1①
<b>SI0</b>	A0②	A0#②	B0②	C1②	C1#②	D1②	D1#②	E1②
<b>FI1</b>	F1①	F1#①	G1①	G1#①	A1①	A1#①	B1①	C2①
<b>SI1</b>	F1②	F1#②	G1②	G1#②	A1②	A1#②	B1②	C2②
<b>FI2</b>	C2#①	D2①	D2#①	E2①	F2①	F2#①	G2①	G2#①
<b>SI2</b>	C2#②	D2②	D2#②	E2②	F2②	F2#②	G2②	G2#②
<b>FI3</b>	A2①	A2#①	B2①	C3①	C3#①	D3①	D3#①	E3①
<b>SI3</b>	A2②	A2#②	B2②	C3②	C3#②	D3②	D3#②	E3②
<b>FI4</b>	F3①	F3#①	G3①	G3#①	A3①	A3#①	B3①	C4①
<b>SI4</b>	F3②	F3#②	G3②	G3#②	A3②	A3#②	B3②	C4②
<b>FI5</b>	C4#①	D4①	D4#①	E4①	F4①	F4#①	G4①	G4#①
<b>SI5</b>	C4#②	D4②	D4#②	E4②	F4②	F4#②	G4②	G4#②
<b>FI6</b>	A4①	A4#①	B4①	C5①	C5#①	D5①	D5#①	E5①
<b>SI6</b>	A4②	A4#②	B4②	C5②	C5#②	D5②	D5#②	E5②
<b>FI7</b>	F5①	F5#①	G5①	G5#①	A5①	A5#①	B5①	C6①
<b>SI7</b>	F5②	F5#②	G5②	G5#②	A5②	A5#②	B5②	C6②
<b>FI8</b>	C6#①	D6①	D6#①	E6①	F6①	F6#①	G6①	G6#①
<b>SI8</b>	C6#②	D6②	D6#②	E6②	F6②	F6#②	G6②	G6#②
<b>FI9</b>	A6①	A6#①	B6①	C7①	C7#①	D7①	D7#①	E7①
<b>SI9</b>	A6②	A6#②	B6②	C7②	C7#②	D7②	D7#②	E7②
<b>FI10</b>	F7①	F7#①	G7①	G7#①	A7①	A7#①	B7①	C8①
<b>SI10</b>	F7②	F7#②	G7②	G7#②	A7②	A7#②	B7②	C8②

	KO0	KO1	KO2	KO3	KO4	KO5	KO6	KO7
<b>KI0</b>	A0③	A0#③	B0③	C1③	C1#③	D1③	D1#③	E1③
<b>KI1</b>	F1③	F1#③	G1③	G1#③	A1③	A1#③	B1③	C2③
<b>KI2</b>	C2#③	D2③	D2#③	E2③	F2③	F2#③	G2③	G2#③
<b>KI3</b>	A2③	A2#③	B2③	C3③	C3#③	D3③	D3#③	E3③
<b>KI4</b>	F3③	F3#③	G3③	G3#③	A3③	A3#③	B3③	C4③
<b>KI5</b>	C4#③	D4③	D4#③	E4③	F4③	F4#③	G4③	G4#③
<b>KI6</b>	A4③	A4#③	B4③	C5③	C5#③	D5③	D5#③	E5③
<b>KI7</b>	F5③	F5#③	G5③	G5#③	A5③	A5#③	B5③	C6③
<b>KI8</b>	C6#③	D6③	D6#③	E6③	F6③	F6#③	G6③	G6#③
<b>KI9</b>	A6③	A6#③	B6③	C7③	C7#③	D7③	D7#③	E7③
<b>KI10</b>	F7③	F7#③	G7③	G7#③	A7③	A7#③	B7③	C8③

**NOMENCLATURE OF KEYS**




**BUTTON MATRIX**




	<b>S00</b>	<b>S01</b>	<b>S02</b>
<b>S10</b>	FUNCTION	METRONOME	ELEC PIANO
<b>S11</b>	—	SONG ▶/■	MODERN
<b>S12</b>	—	CLASSIC	RECORDER

### PRINTED CIRCUIT BOARDS

Main PCB M900-MDA1




Sub PCB M903-PSA1










Console PCB M900-CNA1




Volume PCB M900-CNA2





Jack PCB M902-HPA1




Power Lamp PCB M902-HPA1




Jack PCB M901-JKA1




SD Card PCB M810-SDA1




Pedal PCB M903-PDA1





Keyboard PCB MACP-KYA1





Pedal PCB M903-PDA2





Keyboard PCB MACP-KYA2





Keyboard PCB MACP-KYB1





Keyboard PCB MACP-KYB2





Keyboard PCB MACP-KYC1



Keyboard PCB MACP-KYC2



Keyboard PCB MACP-KYD1



## **DISASSEMBLY**

### **■ CAUTION**


- The photos show a prototype. The appearance of the instrument, such as color, may differ from the actual model.
- To avoid damages to the instrument and the floor, lay the instrument on a mattress or blanket before starting disassembling.
- Some screws are attached with a screw cap.  
Be sure to reattach the screw cap when reassembling.

### **■ Before Starting Repair or Servicing**



- Remove the AC adaptor or the AC cord.
- Remove accessories such as the music stand.
- Remove the pedal unit plug from the pedal connector.

■ Removing the pedal unit

1. Undo two screws.






2. Undo seven screws and then remove the pedal unit.



■ Removing the stand

- 1. Lay down the main unit on the floor.
- 2. Undo eight screws.


NOTE: When you remove the stand, nuts come loose. Do not misplace them.





■ Removing the TOP-BOARD-ASSY


1. Undo 12 screws and then remove the TOP-BOARD-ASSY.



<Cautions for Assembling>



When assembling the TOP-BOARD-ASSY, fasten the screws in the order shown in the illustration below.

NOTE: Screws No.1 through 6 must be fastened while the TOP-BOARD-ASSY is closed.  
Screws No.7 through 12 must be fastened while the TOP-BOARD-ASSY is open.




## ■ Removing the panel unit

1. Undo six screws on the bottom surface of the unit.





2. Undo two screws on both sides of the unit.



3. Undo five screws on the back surface of the unit and then remove the panel unit.

NOTE: The panel unit is connected with FFCs and lead wires.

Do not pull hard or forcibly remove the unit.



■ Wiring of the panel unit

When replacing components, you may have to remove securing bands, cable ties, and wire clips. If you remove these bands and clips, be sure to secure cables back to the original conditions when reassembling.

<Where to secure cables>



○ : Cable tie

○ : Wire clip


Power switch,  
M900-CNA2

Power switch,  
M900-CNA1, M900-CNA2

Power switch, M900-CNA1,  
M900-CNA2, M810-SDA1




Power switch, M900-CNA1,  
M900-CNA2, M810-SDA1



M902-HPA1, M902-HPA2,  
Left speaker

■ Removing the PCB box

- 1. Undo four screws.
- 2. While disengaging two hooks, slide the PCB box in the direction of the arrow to remove it.




■ Wiring of the PCB box

When replacing components, you may have to remove securing bands, cable ties, and wire clips. If you remove these bands and clips, be sure to secure cables back to the original conditions when reassembling.

<Where to secure cables>

○ : Cable tie                      ○ : Wire clip



**<Cautions for Assembling>**

After assembling the PCB box, pull the lead wires and FFCs hanging outside the box so that there is not too much sagging inside the box.


NOTE: Do not pull hard.

**<After replacing the FFCs for the keyboard PCB>**


After replacing the FFCs for the keyboard PCBs, you must assemble the PCB box first and then fold the FFCs in shape.

1. Pull the FFCs in the direction of the arrow so that there is not too much sagging.


NOTE: Do not pull hard.



2. Fold the FFCs into shape as shown in the illustration below.




3. Wrap the formed part of the FFCs with sponge.




■ Removing the main PCB (M900-MDA1)

- 1. Release the locks and remove the two FFCs.
- 2. Remove four connectors.





- 3. Undo six screws and then remove the M900-MDA1 PCB.






■ Removing the sub PCB (M903-PSA1)

- 1. Remove seven connectors.




- 2. Undo four screws and then remove the M903-PSA1 PCB.





## ■ Removing the jack PCB (M901-JKA1)

1. Undo two nuts and then remove the M901-JKA1 PCB.




## ■ Removing the pedal connector

1. Peel the tape off.  
NOTE: The lead wires for the pedal connector are secured in place with securing bands under the tape.
2. Undo two screws on the pedal connector bracket.  
NOTE: The lead wires for the pedal connector run through the ferrite core. When reassembling, be sure to run the lead wire through the ferrite core.




3. Remove the pedal connector from the bracket.








■ Removing the SIDE-BRACKET-ASSY

- 1. Undo four screws on the back surface of the unit.






- 2. Undo two screws and then remove the SIDE-BRACKET-ASSY.



■ Removing the power switch

- 1. Undo two screws and then remove the power switch.






■ Removing the volume PCB (M900-CNA2)

- 1. Remove the volume knob.




- 2. Undo three screws and then remove the M900-CNA2 PCB.



■ Removing the console PCB (M900-CNA1)



- 1. Undo three screws and then remove the bracket

NOTE: You must remove some screws from the back surface of the panel unit.





Screws in the back surface of the panel unit

- 2. Undo 10 screws and then remove the M900-CNA1 PCB.





■ Removing the buttons

Once the M900-CNA1 is removed, you may disassemble the buttons, the LED cover, the LED spacer, and the nonwoven band.





■ Removing the SD card PCB (M810-SDA1)

- 1. Undo two screws on the M810-SDA1 PCB bracket.



- 2. Undo two screws and then remove the M810-SDA1 PCB.




## ■ Removing the jack PCB (M902-HPA1)

1. Peel the tape off.


NOTE: This tape secures the lead wires for the M902-HPA1 and M902-HPA2 PCBs and two securing bands. When assembling, similarly secure the lead wires with securing bands and then tape them in place.

2. Undo two screws and then remove the M902-HPA1 PCB.




## ■ Removing the power lamp PCB (M902-HPA2)

1. Undo six screws and then remove the FRONT-BOARD-ASSY.




2. Undo two screws and then remove the M902-HPA2 PCB.




■ Removing the speaker

- 1. Undo seven screws and then remove the speaker box.
- 2. Undo four screws and then remove the speaker.
- 3. Similarly remove the other speaker.




■ Removing the KY-ASSY

- 1. Undo 25 screws.



- 2. Undo three screws and then remove the KY-ASSY.



## ■ Removing the keys

### <Removing the keys>

To remove the keys, you will need two of the tools described below.

Before removing a black key, you must first remove both white keys on either side of the black key.

White keys may be removed with the same procedures as removing black keys.

### <Tool>

The tool used in the photos in this section was converted from a gardening ID tag. The size and shape of an ID tag accord to the dimensions below.


### <Note on shaping an ID tag>

The thickness of the tool must be within 1.2~1.3 mm.

If the tool is too thin, removing keys become difficult.



If the tool is too thick, it may damage the rib of the chassis.

### <Tool dimensions>




- 1. Insert the two tools between the rib of the chassis and a key.
- 2. When the tools are inserted to a certain depth, the key begins to be lifted and can then be removed.

<Cross-section image>




<Installing the keys>

Refer to the illustration below for the location of each white key.  
Be sure to install each key at its designated location.  
All black keys are the same. A black key may be installed at any correct black-key location.



Install a black key before installing the white keys on either of its sides.  
Follow the same procedures below to install a black or white key.

1. Assemble a key to a hammer.
2. Press the protrusion of the chassis firmly into the keyhole.
3. Press the key to see if it moves properly.



Assemble a key to a hammer.






## ■ Removing the hammers

1. Place the chassis upside down so that the hammers are visible.
2. Press the chassis with the tip of tweezers.
3. While catching a hammer with tweezers, set the tweezers against the resin part of the chassis.
4. Using the chassis-tweezer contact as a fulcrum point, press down against the resin part in the direction of the red arrow in the illustration below, and then disengage the hammer.


NOTE: You must press the resin part of the hammer.

NOTE: Pressing on the metal part of the hammer may damage the area connected to the resin.



<About the hammers>


There are several kinds of hammers.  
The type of a hammer may be identified by the code engraved on it.



Type of Hammer: "W" for a white key, "B" for a black key.  
 Hammer Code: The hammers for white keys are coded W1, W2, W3, and W4.  
 The hammers for black keys are coded B1, B2, B3, and B4.

<Location to install the hammer>

A hammer must be installed at the correct location according to its type.  
The combination of hammers and keys are shown below.






### <Installing the hammers>

Be sure to install each hammer at its designated location. If a hammer does not move smoothly, check if it is installed at the correct location.




Follow the same procedures shown below to install a hammer for both black and white keys.

1. Use the tweezers to set a hammer at its correct location.
2. Press the chassis with the tip of tweezers.
3. Using the chassis-tweezers contact as a fulcrum point, press down the metal part of the hammer in the direction of the red arrow in the illustration below, and then install the hammer.




■ Removing the keyboard PCBs (MACP-KYC1/KYC2, KYD1)



- 1. Remove eight rubber keys.  
NOTE: One rubber key is shorter than the others.



- 2. Remove the nonwoven tape.
- 3. Remove 23 screws.




- 4. Locate the FFC connected on the back of the MACP-KYD1 PCB. Unlock the connector to remove the FFC, and then disengage the MACP-KYC1 PCB, the KYC2 PCB, and the MACP-KYD1 PCB.




**<Installing the keyboard PCBs (MACP-KYC1/KYC2, KYD1)>**


1. Connect the FFC to the MACP-KYD1 PCB and lock the connector.  
Be sure to connect it securely.



2. Install eight rubber keys.  
Be sure to install the short rubber key at the correct location.  
Lightly insert the tip of a rubber key into the PCB first, and then, press it in using the end of a paper clip. Do not press the rubber key forcefully to avoid damaging the rubber key.




3. Secure the MACP-KYC1 PCB, the KYC2 PCB, and the MACP-KYD1 PCB with 23 screws.  
Press the PCBs lightly in the direction of the red arrow in the illustration below while tightening a screw.




■ Removing the keyboard PCBs (MACP-KYA1/KYA2, KYB1/KYB2)



- 1. Remove the nonwoven tape. Unlock the connector and disengage the FFC connecting the MACP-KYA2 PCB and the MACP-KYB1.



- 2. Remove 26 screws.




- 3. Unlock the connector and disengage the FFC connected to the MACP-KYB1 PCB.  
NOTE: When removing the FFC, be careful not to pull it too much in the direction of the red arrow in the illustration, or the PLATE on the back may come loose.




<If the PLATE comes off>




The PLATE is a transparent plastic plate. If the plate comes off, put it on the place where the FFC is, and insert its end into place where the blue line is shown in the image.



4. Remove the keyboard PCBs (MACP-KYA1/KYA2, KYB1/KYB2).




5. Remove eight rubber keys.  
NOTE: One rubber key is shorter than the others.







### <Installing the keyboard PCBs (MACP-KYA1/KYA2, KYB1/KYB2)>

1. Place eight rubber keys on the chassis.  
Be sure to place the short rubber key in the correct location.




2. Connect the FFC to the MACP-KYB1 PCB and lock the connector.  
NOTE: When connecting the FFC, be careful not to pull it too much in the direction of the red arrow in the illustration, or the PLATE on the back may come loose.




<If the PLATE comes off>


The PLATE is a transparent plastic plate. If the plate comes off, put it on the place where the FFC is, and insert its end into place where the blue line is shown in the image.



3. Insert the MACP-KYA1/KYA2 PCB and MACP-KYB1/KYB2 PCB at an angle against the chassis, and place them while paying attention not to misalign the rubber keys.



4. While placing the PCBs, the contact with the rubber keys may come out of alignment. Align them against the red dotted line in the illustration below, lift the PCB once in the direction of the red arrow, and then place them again.



5. Secure the MACP-KYA1/KYA2 PCBs, and the MACP-KYB1/KYB2 PCBs with 26 screws. Press the PCBs lightly in the direction of the red arrow in the illustration below while tightening a screw.



## DIAGNOSTIC PROGRAM

### ■ Initial Setting

1. Connect the AC adaptor.
2. Connect the pedal.  
Even if a pedal unit is unavailable for the test, all the tests except for the pedal check may be performed.
3. "Main" volume: MAX
4. Have a PC and a USB cable ready. (They will be used in the USB check.)  
Operating System: Windows® XP (SP2 or later) \*1  
Windows Vista® \*2  
Mac OS® X (10.3.9, 10.4.11 or later, 10.5.6 or later)  
\*1: Windows XP Home Edition/Windows XP Professional (32 bit)  
\*2: Windows Vista (32 bit)

### ■ How to start the diagnostic program

1. Hold down the "METRONOME", "RECORDER", and "SONG (▶/■)" buttons at the same time, to turn the power ON.
2. Release the "METRONOME", "RECORDER", and "SONG (▶/■)" buttons.
3. After the diagnostic program is launched, Automatic Test will start.  
Select Sequential Test or Single Test after Automatic Test is completed.

Be sure to turn off the power when the test is finished.

### ■ Test Items

This diagnostic program tests the following items.

Selecting the "2. Model check" will run Test 2 (Model check) through 9 (Key check) in sequence.

The "10. Flash Memory check" is a single test. (see page 47)


No.	Test Items	Note
1	Automatic Test	RAM, ROM, LED (Performed at the launch of the diagnostic program)
<b>Sequential Test</b>		
2	Model check	
3	ROM Version check	Internal, External
4	Button check	
5	Pedal check	Pedal
6	Headphones check	Headphones
7	USB check	PC, USB cable
8	SD Card check	SD Card
9	Key check	
<b>Single Test</b>		
10	Flash Memory check	

## ■ Diagnostic program

### 1. Automatic Test

Automatic Test is performed each time the diagnostic program is launched.

1. RAM check and ROM check are performed.  
If a test fails, the "SONG (▶/■)" LED or the "L/R" LED illuminates.
2. LED check is performed.  
The confirmation chords C4, E4, G4 sound, and the LEDs illuminate in the order indicated with the blue arrow as shown in the illustration below.  
The LEDs illuminate repeatedly until the "2. Model check" is performed.



### 2. Model check

1. Press the "FUNCTION" button to perform the "MODEL check".  
The confirmation chords C4, E4, G4 sound.  
If the model is PX-830BP, the "MODERN" LED flashes.


### 3. ROM Version check (Internal/External)

The numbers necessary in the ROM version check are expressed by the combination of the illuminated LEDs.  
<Combinations of LEDs>

- |                                 |  |
|---------------------------------|--|
| 0: All LEDs OFF                 | 5: "ELEC PIANO" + "MODERN" LED             |
| 1: "ELEC PIANO" LED             | 6: "MODERN" + "CLASSIC" LED                |
| 2: "CLASSIC" LED                | 7: "MODERN" + "CLASSIC" + "ELEC PIANO" LED |
| 3: "ELEC PIANO" + "CLASSIC" LED | 8: "RECORDER" LED                          |
| 4: "MODERN" LED                 | 9: "ELEC PIANO" + "RECORDER" LED           |

- Press "FUNCTION" button to perform the "ROM Version check (Internal)". The confirmation chords C4, E4, G4 sound.  
The "ELEC PIANO", "CLASSIC", "MODERN", "RECORDER" LEDs illuminate and the "L" LED flashes while on stand-by.  
NOTE: If you don't wish to perform the "ROM version check (Internal)", go on to the step (3).

<LEDs on stand-by>




- Each time you press the "SONG (▶/■)" button, the status of the LEDs changes. Check to see if the LEDs illuminate in the order shown below.  
Internal ROM (0100): 0 → 1 → 0 → 0 → Stand-by mode

Sequence	Display	LED status
1	(0)	All LEDs OFF
2	(1)	"ELEC PIANO" LED
3	(0)	All LEDs OFF
4	(0)	All LEDs OFF
5	—	Stand-by status as in Step 1

\* While the internal ROM version is indicated, the "L" LED keeps flashing.

- Press "FUNCTION" button to perform the "ROM Version check (External)". The confirmation chords C4, E4, G4 sound.  
The "ELEC PIANO", "CLASSIC", "MODERN", "RECORDER" LEDs illuminate and the "R" LED flashes while on stand-by.  
NOTE: If you don't wish to perform the "ROM version check (External)", go on to the step (1) of the "4. Button check".

<LEDs on stand-by>




- Each time you press the "SONG (▶/■)" button, the status of the LEDs changes. Check to see if the LEDs illuminate in the order shown below.  
External ROM (0100): 0 → 1 → 0 → 0 → Stand-by mode

Sequence	Display	LED status
1	(0)	All LEDs OFF
2	(1)	"ELEC PIANO" LED
3	(0)	All LEDs OFF
4	(0)	All LEDs OFF
5	—	Stand-by status as in Step 3

NOTE: While the external ROM version is indicated, the "R" LED keeps flashing.

## 4. Button check

1. Press the "FUNCTION" button to perform the "BUTTON check".  
The confirmation chords C4, E4, G4 sound, and all LEDs turn off.
2. Press the buttons in the order indicated in the illustration on the bottom.  
Each time the button is pressed, the confirmation chord C6 sounds.  
If a button is not operating properly or a button is pressed in a wrong order, an error tone (F2) sounds.  
NOTE: You cannot cancel this test procedure mid-way.



3. When the "ELEC PIANO" button is pressed at the end, the confirmation chords C4, E4, G4 sound and all LEDs turn off.

## 5. Pedal check

<About the pedal unit>

If there is no pedal unit for testing, go on to the "6. Headphones check".

1. Press the "SOFT" pedal.  
The confirmation chord E4 sounds and the "MODERN" LED lights.
2. Press the "SOSTENUTO" pedal.  
The confirmation chord G4 sounds and the "CLASSIC" LED lights.
3. Press the "DAMPER" pedal (ON HALF).  
The confirmation chord C4 sounds and the "ELEC PIANO" LED flashes.
4. Press the "DAMPER" pedal firmly (ON FULL).  
The confirmation chord C4 sounds and the "ELEC PIANO" LED lights.

## 6. Headphones check

---

1. Press "FUNCTION" button to perform the "Headphones check".  
The confirmation chords C4, E4, G4 sound and the "L" LED lights.
2. Connect the headphones to the jack in the front of the main unit.  
The "L" LED turns off and the "R" LED illuminates.
3. Check to see if you can hear test sound from the headphones by pressing the "A4" key.
4. Remove the headphones from the jack.  
The "R" LED turns off and the "L" LED illuminates.
5. Connect the headphones to the jack in the back of the main unit.  
The "L" LED turns off and the "R" LED illuminates.
6. Check to see if you can hear test sound from the headphones by pressing the "A4" key.
7. Remove the headphones from the jack.  
The "R" LED turns off and the "L" LED illuminates.

## 7. USB check

---

1. Press the "FUNCTION" button to perform the "USB check".  
The confirmation chords C4, E4, G4 sound.
2. Connect PX-830BP to the PC with a USB cable.
3. Press "MODERN" button.  
When the USB check completes, the "R" LED will light and the confirmation chord C6 sounds.
4. Disconnect the USB cable.

## 8. SD Card check

---

1. Press the "FUNCTION" button to perform the "SD Card check".
2. Insert an SD card into the SD card slot.
3. Press the "MODERN" button.  
When the SD Card check completes, the "R" LED will light and the confirmation chord C6 sounds.
4. Remove the SD card.



## **9. Key check**

---

1. Press the "FUNCTION" button.  
The confirmation chords C4, E4, G4 sound.
2. Press the "FUNCTION" button.  
The confirmation chords C4, E4, G4 sound twice.
3. Press the "FUNCTION" button to perform the "Key check".
4. Confirm that a test tone (approx. 500 Hz) sounds from the left speaker while a key is pressed half way.  
Check all white and black keys.
5. Confirm that a test tone (approx. 500 Hz) sounds from the left speaker and a high-pitched test tone (approx. 2 kHz) sounds from the right speaker while a key is pressed completely.  
Check all white and black keys.
6. Press the "POWER" button to turn off the power.

## **10. Flash Memory check**


---

1. Boot the diagnostic program.
2. Hold down the "ELEC PIANO" button for 2 seconds.  
The "ELEC PIANO" LED illuminates instantaneously, and the confirmation chords C4, E4, G4 sound.
3. Press the "POWER" button to turn off the power.

## Operation after replacing the main PCB or the keyboard parts


Make sure to perform the following procedure after replacing the main PCB or the keyboard parts. Applicable parts number on the Parts List: No.1 for the main PCB, No. 53 to 85 for the KY-ASSY or the KY-ASSY component parts

### Procedure




1. Hold down the "FUNCTION", "METRONOME", and "ELEC PIANO" buttons at the same time, to turn the power ON.  
All LEDs are lit.
2. Release the "FUNCTION", "METRONOME", and "ELEC PIANO" buttons.  
All the LEDs turn off except "L" and "R" LEDs.
3. Press the "METRONOME" button.  
The "R" and "MODERN" LEDs are lit.
4. Press the "MODERN" button.  
The "R" and "CLASSIC" LEDs are lit.
5. Press the "CLASSIC" button.  
The "R" and "ELEC PIANO" LEDs are lit.
6. Press the "ELEC PIANO" button.  
The LEDs on both side of the "SONG (▶/■)" mark, the "R" LED, and the "ELEC PIANO" LED are lit.
7. Press the "RECORDER" and "METRONOME" buttons at the same time.
8. Press the "POWER" button to turn off the power.


EXPLODED VIEW




KEY ASSY



Do not allow the sponge to run off the edge.



STAND



	x 8		x 2		x 1
	x 8		x 2		x 1
	x 2		x 2		x 1
	x 5		x 6		x 1
	x 3				

# PARTS LIST

## PX-830BP

Notes:

1. Prices and specifications are subject to change without prior notice.
2. Refer to the latest "Parts Price Code" at "PARTS FINDER" on the Casio Service WEB site (<https://www.servicecasio.com>).
3. As for spare parts order and supply, refer to the "GUIDEBOOK for Spare parts Supply", published separately.
4. The numbers in item column correspond to the same numbers in drawing.

- 1 PX-830\_BLACKPOLISH\_DI
- 2 PX-830\_BLACKPOLISH\_EU
- 3 PX-830\_BLACKPOLISH\_UK
- 4 PX-830\_BLACKPOLISH\_US

N	Item	Parts No.	Parts Name	Specification	Q'TY				Price Code	R	Remarks
					1	2	3	4			
MAIN PCB											
	1	10348104	PCB ASSY / MDA1	TK-RJM509989*001	1	1	1	1		B	MAIN PCB
	CN10	10257512	CONNECTOR	UBR23-4K5G00	1	1	1	1		C	USB connector
	D31	10276977	DIODE	L1SS400T1G	1	1	1	1		X	
	IC13	10256338	IC	CS4351-CZZR	1	1	1	1		X	
	IC1	10241413	IC	R1151N001C-TR-F	1	1	1	1		X	
	IC12	10197808	IC	TC7SZ08FU(TE85L.F)	1	1	1	1		X	
	IC4	10197554	IC	TC7SZ126FU(TE85L.F)	1	1	1	1		X	
	IC5	10255468	LSI	MB91F036PFF-GE1	1	1	1	1		C	
	IC14	10333782	LSI	UPD65943GK-F659EUA	1	1	1	1		C	
	IC2	10333111	MEMORY	MD56V82160-6TAZ03B	1	1	1	1		X	
	IC6	10333112	MEMORY	S29GL256P90TFCR20D	1	1	1	1		X	
	L47	10193074	COIL	DLW21HN181SQ2L	1	1	1	1		X	
	Q1-Q3,Q8,Q9	69409403	TRANSISTOR	2SA1576AT106R	5	5	5	5		X	
	Q7	22592764	TRANSISTOR	2SB1188T100Q	1	1	1	1		X	
	Q4-Q6,Q10	69300298	TRANSISTOR	2SC4081T106R	4	4	4	4		X	
	X1,X31	10334293	RESONATOR	9C12000163	2	2	2	2		X	
SUB PCB											
	2	10348106	PCB ASSY / PSA1	TK-RJM509990*001	1	1	1	1		C	PSA1 PCB
	IC3	10257492	IC	NJM78M12FA	1	1	1	1		X	
	IC1	10201503	IC	PQ1CG21H2FZH	1	1	1	1		X	
	J1	10342138	CONNECTOR	LGP7031-0900FC	1	1	1	1		B	DC jack
	L3	10342135	COIL	02249-T556	1	1	1	1		X	
	L14	10231919	COIL	RB53-856396NP	1	1	1	1		X	
	L4,L13	10231920	COIL	RB53-856397NP	2	2	2	2		X	
	L9	10232457	COIL	R1I7-860400NP	1	1	1	1		X	
	L6,L7,L11,L12	10342335	COIL	RP1315BNP-220M-T	4	4	4	4		X	
	D9,D10,D12	10276977	DIODE	L1SS400T1G	3	3	3	3		X	
	D15,D16	10308381	DIODE	LUDZS7.5BT1G	2	2	2	2		X	
	D3	10342143	DIODE	RB075B40STL	1	1	1	1		X	
	D4	10210387	DIODE	RSX101VA-30TR	1	1	1	1		X	
	IC5	10211950	IC	NJM2068M-D(TE1)	1	1	1	1		X	
	IC2	10335105	LSI	R2A15108SP-W00T	1	1	1	1		C	
	Q4-Q12	69300298	TRANSISTOR	2SC4081T106R	9	9	9	9		X	
	Q15,Q16	10305853	TRANSISTOR	KTD1304-RTK/P	2	2	2	2		X	
	D11	10334295	DIODE	LUDZS12BT1G	1	1	1	1		X	
	IC4	10343240	IC	BH3544F-E2	1	1	1	1		X	

- 1 PX-830\_BLACKPOLISH\_DI
- 2 PX-830\_BLACKPOLISH\_EU
- 3 PX-830\_BLACKPOLISH\_UK
- 4 PX-830\_BLACKPOLISH\_US

N	Item	Parts No.	Parts Name	Specification	Q'TY				Price Code	R	Remarks
					1	2	3	4			
JACK PCB											
	3	10348107	PCB ASSY / JKA1	TK-RJM509991*001	1	1	1	1		C	JKA1 PCB
	J503	10206815	CONNECTOR	JY-6314*01-030	1	1	1	1		B	Line out L/MONO
	J504	10206816	CONNECTOR	JY-6314*01-130	1	1	1	1		B	Line out R
	L503,L504	10231920	COIL	RB53-856397NP	2	2	2	2		X	
PCB BOX											
	4	10342241	BOX / PCB	RJM509521-001V01	1	1	1	1		X	Box for PCB
	5	10342275	METAL SHEET	RJM509570-001V01	1	1	1	1		X	
	6	10348220	V-0 SHEET	RJM509973-001V01	1	1	1	1		X	
CONSOLE PCB											
	7	10348098	PCB ASSY / CNA1	TK-RJM509984*001	1	1	1	1		X	CNA1 PCB
	D601,D604,D605, D610-D612	10336974	LED	26-21/R1	6	6	6	6		X	
	D602	10336975	LED	26-21/Y1	1	1	1	1		X	
	SW601-SW607	10337110	SWITCH	TP-1138A-10-100GF	7	7	7	7		X	
	D603,D606	10209564	LED	KPTD-3216SURCK	2	2	2	2		X	
	8	10348099	PCB ASSY / CNA2	TK-RJM509987*001	1	1	1	1		C	CNA2 PCB
	VR601	69308726	VARIABLE RESISTOR	RK09K12C0D0W	1	1	1	1		B	Main volume
	9	10348100	PCB ASSY / SDA1	TK-RJM509980*001	1	1	1	1		X	SDA1 PCB
PANEL UNIT											
	10	10348101	PANEL ASSY	TK-RJM509810*001	1	1	1	1		X	
	11	10342216	PANEL CASE	RJM509482-001V01	1	1	1	1		X	
	12	10348102	SPEAKER COVER / L	TK-RJM510006*001	1	1	1	1		X	
	13	10348103	SPEAKER COVER / R	TK-RJM510007*001	1	1	1	1		X	
	14	10342256	KNOB / ROTARY	M341402-001	1	1	1	1		C	
	15	10342240	BUTTON / POWER	RJM509558-001V01	1	1	1	1		C	
	16	10337938	KEY FELT	RJM509922-001	1	1	1	1		X	
	17	10053728	FABRIC TAPE -10-42	M440240-2	6	6	6	6		X	
	18	10342127	BUTTON / TACT / A	RJM509408-002V01	3	3	3	3		X	
	19	10337030	BUTTON / TACT / B	RJM509396-002	4	4	4	4		X	
	20	10342191	COVER / LED	RJM509559-001V01	6	6	6	6		X	
	21	10342192	SPACER / LED / C	RJM509413-002V01	4	4	4	4		X	
	22	10342193	SPACER / LED / C	RJM509413-003V01	1	1	1	1		X	
	23	10342176	FABRIC SHEET	RJM509959-001V01	1	1	1	1		X	
	24	10342272	BRACKET / SD	RJM509562-001V01	1	1	1	1		X	
	25	10334406	SWITCH	SDDL1017U	1	1	1	1		X	Power switch
	26	10336251	HARNESS	TD-EH3P105M902	1	1	1	1		X	For power switch
	27	10348096	SIDE BRACKET ASSY / L	TK-RJM509814*001	1	1	1	1		X	
	28	10348097	SIDE BRACKET ASSY / R	TK-RJM509815*001	1	1	1	1		X	
	29	10342124	BACK BOARD	RJM509536-001V01	1	1	1	1		X	
	30	10349173	STOPPER	RJM510197-001	2	2	2	2		X	
	31	10342132	BRACKET / PANEL	RJM509561-001V01	5	5	5	5		X	
	32	10342310	BRACKET / PANEL	RJM509565-001V01	5	5	5	5		X	

- 1 PX-830\_BLACKPOLISH\_DI
- 2 PX-830\_BLACKPOLISH\_EU
- 3 PX-830\_BLACKPOLISH\_UK
- 4 PX-830\_BLACKPOLISH\_US

N	Item	Parts No.	Parts Name	Specification	Q'TY				Price Code	R	Remarks	
					1	2	3	4				
LOW CASE UNIT & TOP CASE UNIT												
N	33	10348108	LOWER BOARD ASSY	TK-RJM509823*001	1	1	1	1		X		
	34	10337993	SPEAKER	C12J08	2	2	2	2		X		
	35	10345989	HARNESS / SPEAKER	EF-EH2P066M903	2	2	2	2		X		
	36	69261570	SPONGE -35-130	M440013-002	2	2	2	2		X		
	37	10348584	PCB ASSY / HPA1	TK-RJM509998*001	1	1	1	1		C	HPA1 PCB	
	J701,J702	10171449	CONNECTOR	JY-6360*04-070	2	2	2	2		B	Headphones jack	
	L701,L702	10231919	COIL	RB53-856396NP	2	2	2	2		X		
	38	10047599	FABRIC TAPE -10-100	M440710-001	1	1	1	1		X		
	39	10343859	DOUBLE-FACED TAPE	RJM510102-001	2	2	2	2		X		
	40	10345990	HARNESS	EF-SMP5P074M903	1	1	1	1		X	Pedal connector	
	41	10337917	FABRIC TAPE -15-30	RJM509924-001	2	2	2	2		X		
	42	10348913	F-BRD-ASSY	TK-RJM510152*001	1	1	1	1		X		
	43	10348585	PCB ASSY / HPA2	TK-RJM509999*001	1	1	1	1		X	HPA2 PCB	
	D701	10203050	LED	231XHD	1	1	1	1		X		
	44	10218677	BRACKET	RJM505977-001V03	5	5	5	5		X		
	45	10348085	BRACKET	RJM510180-001V01	1	1	1	1		X		
	46	10208428	FERRITE CORE	CTRC-0813(B)	1	1	1	1		X		
	N	47	10348912	T-BRD-ASSY	TK-RJM510153*001	1	1	1	1		X	
	48	10342257	RUBBER FOOT	RJM510070-001V01	2	2	2	2		X		
	N	48-1	10346674	D-FACE-15-15	RJM510136-001V01	2	2	2	2		X	
49	10334382	BOX / SPEAKER	RJM509334-001	2	2	2	2		X			
50	10246603	BOLT	YD-0319303	2	2	2	2		X			
51	10348094	FRONT SUPPORT	TK-RJM510075*001	1	1	1	1		X			
52	10347096	RATING-ST-M908A	RJM504373-032V01	1	1	1	1		X			
KEYBOARD UNIT												
	53	10348976	KEYBOARD ASSY	TK-RJM510156*005	1	1	1	1		C		
	54	10337877	BLACK KEY	RJM502797-003	36	36	36	36		B		
	55	10338014	WHITE KEY / SA	RJM502795-004	1	1	1	1		X		
	56	10338011	WHITE KEY / B	RJM502794-003	1	1	1	1		X		
	57	10338012	WHITE KEY / CEGB	RJM502862-003	7	7	7	7		B		
	58	10338013	WHITE KEY / DFA	RJM502863-003	7	7	7	7		B		
	59	10338015	WHITE KEY / SC	RJM502796-004	1	1	1	1		X		
	60	10341062	HAMMER ASSY / W1	TK-RJM509600*001	13	13	13	13		C		
	61	10341063	HAMMER ASSY / W2	TK-RJM509601*001	13	13	13	13		C		
	62	10341064	HAMMER ASSY / W3	TK-RJM509602*001	13	13	13	13		C		
	63	10341065	HAMMER ASSY / W4	TK-RJM509603*001	13	13	13	13		C		
	64	10341066	HAMMER ASSY / B1	TK-RJM509604*001	9	9	9	9		C		
	65	10341067	HAMMER ASSY / B2	TK-RJM509605*001	9	9	9	9		C		
	66	10341068	HAMMER ASSY / B3	TK-RJM509606*001	9	9	9	9		C		
	67	10341069	HAMMER ASSY / B4	TK-RJM509607*001	9	9	9	9		C		
	68	10334333	RUBBER CONTACT / AG1	RJM509219-001	7	7	7	7		A		
	69	10334334	RUBBER CONTACT / GC1	RJM509220-001	1	1	1	1		X		
	70	10340880	PCB ASSY / KYC KYD	TK-RJM509609*001	1	1	1	1		C	KYC,KYD PCB	
	D601-D628	10301580	DIODE	LM1MA142WAT1G	28	28	28	28		X		
	D801-D818	10301580	DIODE	LM1MA142WAT1G	18	18	18	18		X		
	71	10336110	CABLE	UL2896-20-335-MACP	1	1	1	1		C		
	72	10334298	FABRIC TAPE -15X270	M411937-001V01	1	1	1	1		C		




- 1 PX-830\_BLACKPOLISH\_DI
- 2 PX-830\_BLACKPOLISH\_EU
- 3 PX-830\_BLACKPOLISH\_UK
- 4 PX-830\_BLACKPOLISH\_US


N	Item	Parts No.	Parts Name	Specification	Q'TY				Price Code	R	Remarks
					1	2	3	4			
	73	10341198	PCB ASSY / KYA	TK-RJM509622*001	1	1	1	1		C	KYA PCB
	D601-D644	10294400	DIODE	LM1MA142WKT1G	44	44	44	44		X	
	74	10341199	PCB ASSY / KYB	TK-RJM509624*001	1	1	1	1		C	KYB PCB
	D801-D844	10294400	DIODE	LM1MA142WKT1G	44	44	44	44		X	
	75	10334331	RUBBER CONTACT / AG2	RJM509217-001	7	7	7	7		A	
	76	10334332	RUBBER CONTACT / GC2	RJM509218-001	1	1	1	1		X	
	77	37195442	CABLE	N30315B1B05-UL2896	1	1	1	1		C	
	78	10336111	CABLE	UL2896-20-120-MACP	1	1	1	1		C	
	79	10164446	FABRIC TAPE -20-120	RJM502073-002	2	2	2	2		X	
	80	10340855	FELT / KEY	RJM510067-001	1	1	1	1		X	
	81	10138691	FELT / KEY	RJM503562-001	1	1	1	1		X	
	82	10306460	PLATE	RJM505864-001	2	2	2	2		X	
	83	10343387	FABRIC TAPE	RJM510100-001	1	1	1	1		X	
	84	10334393	FELT / HAMMER	RJM509655-001	1	1	1	1		X	
	85	10294093	FELT / HAMMER	TK-RJM507910*001	1	1	1	1		X	
	86	10281936	SPONGE -35-80	M440930-001	2	2	2	2		X	
	87	69261570	SPONGE -35-130	M440013-2	1	1	1	1		X	
STAND											
N	88	10351123	STAND BOARD ASSY / B	TK-RJM510183*001	1	1	1	1		X	
	89	10342298	STAND BOARD / B	RJM509541-001V01	1	1	1	1		X	
N	90	10348908	ST-BRD-L-ASSY	TK-RJM510149*001		1	1			X	
N	90	10348910	ST-BRD-L-ASSY	TK-RJM510149*002	1			1		X	
	91	10134829	RUBBER FOOT -D23	RJM503203-001V01	4	4	4	4		X	
	92	10342295	STAND BRACKET / L	RJM509563-001V01	1	1	1	1		X	
N	93	10348909	ST-BRD-R-ASSY	TK-RJM510150*001		1	1			X	
N	93	10348911	ST-BRD-R-ASSY	TK-RJM510150*002	1			1		X	
	93	40134829	RUBBER FOOT -D23	RJM503203-001V01	2	2	2	2		X	
	94	10342296	STAND BRACKET / R	RJM509571-001V01	1	1	1	1		X	
	95	10343868	FOOT -23X53	RJM503236-001V02	2	2	2	2		X	
	96	10348092	PEDAL BOARD ASSY	TK-RJM509802*001			1	1		C	
	96	10351124	PEDAL BOARD ASSY	TK-RJM509802*002	1					C	
	96	10351125	PEDAL BOARD ASSY	TK-RJM509802*003		1				C	
	97	10346680	PEDAL BOARD	RJM510137-001V01	1	1	1	1		X	
	98	10342290	BRACKET / STAND	RJM509564-001	1	1	1	1		X	
	99	10308823	RUBBER FOOT -H20	RJM509026-001V01	2	2	2	2		X	
	100	10342232	PEDAL BRACKET / L	RJM509572-001V01	1	1	1	1		X	
	101	10342233	PEDAL BRACKET / R	RJM509573-001V01	1	1	1	1		X	
	102	10348093	PEDAL UNIT	TK-RJM510080*001	1	1	1	1		B	
	103	10287951	SPONGE	RJM508328-001V01	3	3	3	3		X	
	VR1	10257246	VARIABLE RESISTOR	XV09411N895Z5K1050	1	1	1	1		X	For pedal
	104	10339497	HARNESS	EF-SMR5P155MP5	1	1	1	1		X	For pedal
	105	10348088	SCREW SET	TK-RJM509797*001	1		1	1		X	
	105	10348091	SCREW SET	TK-RJM509797*002		1				X	
ACCESSORIES											
	X-1	10347080	AC ADAPTOR	AD-E24250LW-P2	1	1	1	1		C	
	X-2	10337904	CORD SET	UC2LT-M003A	1			1		C	for US AC120V
	X-3	10318804	CORD	EC2LT-M001A	1	1				C	for EU AC230V
	X-4	10318806	CORD	BC2LT-M001A			1			C	for UK AC230V
	X-5	10318805	CORD	KC2LT-M001A	1					C	for Korea AC230V
	X-6	10347467	DUST COVER	RJM510167-001V01	1	1	1	1		X	

# SCHEMATIC DIAGRAMS


## Main PCB M900-MDA1 (1/2)




Main PCB M900-MDA1 (2/2)




Sub PCB M903-PSA1




Not used




Console PCB M900-CNA1




Volume PCB M900-CNA2



Jack PCB M901-JKA1




Jack PCB M902-HPA1




JUMPER RESISTOR		
3216 SIZE		
R701	R703	R705
0	0	0
-W-	-W-	-W-
R702	R704	R706
0	0	0
-W-	-W-	-W-


Power Lamp PCB M902-HPA2



SD Card PCB M810-SDA1




Pedal PCB M903-PDA1/M903-PDA2






Keyboard PCB MACP-KYA1

# PWB-MACP-KYA1



# PWB-MACP-KYA2




KC7	P656
KC6	P658
KC5	P660
KC4	P662
KC3	P664
KC2	P666
KC1	P668
KC0	P670
SI2	P672
SI1	P674
SI0	P676
FT0	P678

14pin\_WIRE  
CN602  
(to KYA1/CN601)

20FMZ-ST(LF) (SN)  
CN603  
(to KYB1/CN801)


P709	FT0
P711	FT1
P713	FT2
P715	FT3
P717	FT4
P719	FT5
P721	FT6
P723	FT7
P725	FT8
P727	FT9
P729	FT10
P731	FT11
P733	FT12
P735	FT13
P737	FT14
P739	FT15
P741	FT16
P743	FT17
P745	FT18
P747	FT19
P749	FT20
P751	FT21
P753	FT22
P755	FT23
P757	FT24
P759	FT25
P761	FT26
P763	FT27
P765	FT28
P767	FT29
P769	FT30
P771	FT31
P773	FT32
P775	FT33
P777	FT34
P779	FT35
P781	FT36
P783	FT37
P785	FT38
P787	FT39
P789	FT40

# PWB-MACP-KYB1




Keyboard PCB MACP-KYB2

PWB-MACP-KYB2




Keyboard PCB MACP-KYC1

# PWB-MACP-KYC1




Keyboard PCB MACP-KYC2

PWB-MACP-KYC2



Keyboard PCB MACP-KYD1

# PWB-MACP-KYD1



Ver. 1 : Nov. 2009

- Correction of the DISASSEMBLY (P32)

Ver. 2 : Dec. 2009

- Correction of the PARTS LIST (P55)

Ver. 3 : Dec. 2009

- Correction of the DIAGNOSTIC PROGRAM (P48)
- Correction of the EXPLODED VIEW (P49 and P50)
- Correction of the PARTS LIST (P54 and P55)

Ver. 4 : Mar. 2010

- Correction of the PARTS LIST (P52 to P55)

**CASIO COMPUTER CO.,LTD.**

Overseas Service Division

6-2, Hon-machi 1-Chome  
Shibuya-ku, Tokyo 151-8543, Japan